

## INSTRUCTIONS FOR GS110 EZSUPERSEAL

For best results, ensure surfaces are completely dry and free of dust, grime or grease. Install while temperatures are roughly between 40° & 90° F (5°-32° C).

Installation: Unwind approximately 12" to start. Remove backing paper. Press adhesive side of tape firmly onto window or door frame. Apply around door or window as needed and cut excess with scissors or razor. Windows: Apply on upper and lower window sashes between window and window sill. Doors: Apply to door stop molding across the top and down latch side. On hinge side, apply to door frame next to molding.